

IN-LINE WORKSTATION -HEAVY-DUTY ASSEMBLY INSTRUCTIONS

PARTS & HARDWARE INCLUDED: Do not remove components from cartons prior to assembly. Use the packing list to locate components. Keep hardware kits in labeled packaging until ready to use.

	COMPONENTS	KIT-21	KIT-02
	Worksurface (2)	5/16" Flat Washers (4)	5/16" Flat Washers (8)
	Frame (2) Swaybrace (2) Leg Sections (3)	5/16-18 x 3/4" HHCS (4)	5/16-18 x 3/4" HHCS (8) Joining Plates (4)
	Joining Plate (1)	КІТ-04	KIT-23A
	End Caps (4)	Z Clips (4/6) 1/4" Flat Washers (4/6) 1/4-20 x 3/4" RHMS (4/6)	5/16" Flat Washers (4) 5/16-18 Serrated Flange Nuts (2) 5/16-18 x 3/4 HHCS (2)


NOTE: There will be hardware remaining after assembling in-line workstations as kits are assigned per part.

ASSEMBLY TIPS


- Lay tops upside down before you begin assembly of the Frames & Legs. Pay attention to the orientation of the Tops (rear inserts are closer to the edge).
- Front of Frames bears the Workplace nameplate.
- Hand-tighten all hardware until specified otherwise.
- Two people are required to turn the assembly workstation right-side-up.

ADJUSTING THE WORKHEIGHT

- Legs are typically set at 34"H and adjust in 1-1/2" increments.
- Remove the hardware from above and below the horizontal crossmember and adjust the leg extender. Replace hardware & tighten securely.



Position Frames flush to rear edge of Worksurface. Position Swaybrace on Frame followed by Legs. Fasten Swaybraces to back of Legs using KIT-21. Where Swaybraces abut at Intermediate Leg, install Joining Plate with KIT-23A.



WORKPLACE MODULAR SYSTEMS

800-258-9700

Instructions to attach Casters and Mobile Supports.

LIT #WHD-03 (REV. 10/18)