

## CORNER QUAD WORKSTATION ASSEMBLY INSTRUCTIONS

**PARTS & HARDWARE INCLUDED**: Do not remove components from cartons prior to assembly. Use the packing list to locate components. Keep hardware kits in labeled packaging until ready to use.

$\sim$	COMPONENTS	KIT-21	KIT-97	KIT-81
0	Frames (2)	5/16" Flat Washers (4)	1/4-20 x 3/4 HH	5/16" Flat Washers (8)
	Corner Filler (1)	5/16-18 x 3/4" HHCS (4)	Serrated Flange (4)	5/16-18 x 3/4"
	Legs (3)			Serrated Flange (8)
	Assembled Wing A (1)	KIT-04	KIT-18	
Sar	Assembled Wing B (2)	Z Clips (4/6)	10 x 3/4" Drive Screw (4)	
	Worksurfaces (3)	1/4" Flat Washers (4/6)	1/4" Flat Washers (4)	
		1/4-20 x 3/4" RHMS (4/6)		
*				

**NOTE:** Wing A and Wing B framework should be assembled per Standard Workstation Instructions, no Legs will be assembled where Wings attach to Corner Frame. Do Not install Worksurfaces until wings are connected to Corner Unit.

## ASSEMBLY TIPS

- Assemble and fasten Corner Frames & Leg upside down. Flip Framework right-side up before attaching Wings or Tops.
- Worksurfaces are used in multiple configurations. Inserts should line up; if not use KIT-18 to attach Z Clips found in KIT-04.
- Hand-tighten all hardware until specified otherwise.
- Two people are required to turn the assembled workstation right-side-up.

## **ADJUSTING THE WORKHEIGHT**

- Leg Sections are typically set at 34"H and adjust in 1-1/2" increments.
- Remove the hardware from above and below the horizontal crossmember and adjust the leg extender. Replace hardware & tighten securely.



