



KEYBOARD TRAY: Do not remove components from cartons prior to assembly. Use the packing list to locate components. Keep hardware kits in labeled packaging until ready to use.

ASSEMBLY TIPS



- Keyboard Trays may be mounted with the worksurface assembled, except on Heavy-Duty units where brackets must be positioned on Frame before the Worksurface.
- Remove Keyboard Tray from case and set aside before beginning.

KEYBOARD TIPS


- To Remove: pull tray out and on left and right rear, push one clip up and the other down to release from slide.
- To place into case: line up slides, using some pressure slide back in. DO NOT FORCE in.
- Keyboard Tray will be stiff upon initial assembly. Open and close numerous times to loosen up the slides.



ON A STANDARD* WORKSTATION: Mount Keyboard Tray, aligning pre-drilled holes in tray case with Frame. Fasten using KIT-17A. Return tray to case.



ON A HEAVY-DUTY WORKSTATION:** Hang brackets from Frame (see Assembly Tips). Mount case to brackets with fasteners from KIT-17A. Return tray to case.



ON A CORNER* WORKSTATION: Mount Keyboard Tray by aligning holes in tray case with Frame. Fasten using KIT-17A. Return tray to case.

*Standard & Corner Frames have brackets mounting provisions in the framework.

**On Heavy-Duty Tables, drawers must be positioned 7" from end of Frame.

HARDWARE INCLUDED

KIT-17A (2 per Tray)

1/4-20 x 1/2" RHMS (2)

1/4" Flat Washers (2)

1/4-20 Serrated Flange Nuts (2)